

## **FOOTREST KIT 501-TP INSTALLATION**



1



2



3

*When riding long distances legs get tired as they are in the same position all the time (1). Mounted on the footboards the footrest pegs allow you to rest your feet and legs; they can be fitted either with the pegs on the engine guard (2) or without them (3).*



*The screws are made of stainless steel, other parts of aluminium. The body pieces on the left are anodized, the sleeves in the middle hard anodized and the end pieces chrome-plated.*



*Detach and dismantle the footboards. Take the parts out of the package and replace the ball head screws on the end piece with countersunk screws. Move the body piece a few times back and forth against the bottom of the footboard, as shown in the picture. The sharp end of the screw has now drawn the area in which you can drill one or more hole for the installation.*



*After drilling the holes, mount the body pieces of the footrest pegs to a desired position. Mount the sleeves and end pieces. Secure the screw joint by locking.*